# Product data sheet **Characteristics**

# ATV61HU75N4

variable speed drive ATV61 - 7.5kW 10HP -380...480V - IP20



Range of product	Altivar 61
Product or component type	Variable speed drive
Product specific appli- cation	Pumping and ventilation machine
Component name	ATV61
Motor power kW	7.5 kW 3 phases at 380480 V
Motor power hp	10 hp 3 phases at 380480 V
Power supply voltage	380480 V (- 1510 %)
Supply number of phases	3 phases
Line current	27 A for 380 V 3 phases 7.5 kW / 10 hp 22.2 A for 480 V 3 phases 7.5 kW / 10 hp
EMC filter	Level 3 EMC filter
Assembly style	With heat sink
Apparent power	17.8 kVA for 380 V 3 phases 7.5 kW / 10 hp
Maximum prospective line lsc	22 kA 3 phases
Maximum transient cur- rent	21.1 A for 60 s 3 phases
Nominal switching fre- quency	12 kHz
Switching frequency	1216 kHz with derating factor 116 kHz adjustable
Asynchronous motor control	Voltage/Frequency ratio, 2 points Voltage/Frequency ratio, 5 points Flux vector control without sensor, standard Voltage/Frequency ratio - Energy Saving, quadratic U/f
Synchronous motor control profile	Vector control without sensor, standard
Communication port protocol	CANopen Modbus
Type of polarization	No impedance for Modbus
Option card	Profibus DP V1 communication card Profibus DP communication card Multi-pump card Modbus/Uni-Telway communication card Modbus TCP communication card Modbus Plus communication card METASYS N2 communication card LonWorks communication card Interbus-S communication card I/O extension card Fipio communication card Ethernet/IP communication card DeviceNet communication card Controller inside programmable card CC-Link communication card BACnet communication card



# Complementary

Complementary	
Product destination	Asynchronous motors Synchronous motors
Power supply voltage limits	323528 V
Power supply frequency	5060 Hz (- 55 %)
Power supply frequency limits	47.563 Hz
Continuous output current	17.6 A at 12 kHz, 380 V 3 phases 14 A at 12 kHz, 460 V 3 phases
Speed drive output frequency	0.11000 Hz
Speed range	1100 in open-loop mode, without speed feedback
Speed accuracy	+/- 10 $\%$ of nominal slip for 0.2 Tn to Tn torque variation without speed feedback
Torque accuracy	+/- 15 % in open-loop mode, without speed feedback
Transient overtorque	130 % of nominal motor torque, +/- 10 % for 60 s
Braking torque	30 % without braking resistor <= 125 % with braking resistor
Regulation loop	Frequency PI regulator
Motor slip compensation	Adjustable Automatic whatever the load Can be suppressed Not available in voltage/frequency ratio (2 or 5 points)
Diagnostic	1 LED red presence of drive voltage
Output voltage	<= power supply voltage
Electrical isolation	Between power and control terminals
Type of cable for mounting in an enclosure	Without mounting kit: 1-strand IEC cable at 45 °C, copper 90 °C XLPE/EPR Without mounting kit: 1-strand IEC cable at 45 °C, copper 70 °C PVC With UL Type 1 kit: 3-strand UL 508 cable at 40 °C, copper 75 °C PVC With an IP21 or an IP31 kit: 3-strand IEC cable at 40 °C, copper 70 °C PVC
Electrical connection	L1/R, L2/S, L3/T, U/T1, V/T2, W/T3, PC/-, PO, PA/+, PA, PB terminal 6 mm <sup>2</sup> / AWG 8 AI1-/AI1+, AI2, AO1, R1A, R1B, R1C, R2A, R2B, LI1LI6, PWR terminal 2.5 mm <sup>2</sup> / AWG 14
Tightening torque	L1/R, L2/S, L3/T, U/T1, V/T2, W/T3, PC/-, PO, PA/+, PA, PB 3 N.m / 26.5 lb.in Al1-/Al1+, Al2, AO1, R1A, R1B, R1C, R2A, R2B, Ll1Ll6, PWR 0.6 N.m
Supply	Internal supply 24 V DC (2127 V), <= 200 mA for overload and short-circuit pro- tection Internal supply for reference potentiometer (1 to 10 kOhm) 10.5 V DC +/- 5 %, <= 10 mA for overload and short-circuit protection External supply 24 V DC (1930 V), 30 W
Analogue input number	2
Analogue input type	Al2 software-configurable voltage 010 V DC, input voltage 24 V max, impedance 30000 Ohm, resolution 11 bits Al2 software-configurable current 020 mA, impedance 242 Ohm, resolution 11 bits Al1-/Al1+ bipolar differential voltage +/- 10 V DC, input voltage 24 V max, resolu- tion 11 bits + sign
Sampling time	Discrete input LI6 (if configured as logic input)2 ms, +/- 0.5 ms Discrete input LI1LI5 2 ms, +/- 0.5 ms Analog output AO1 2 ms, +/- 0.5 ms Analog input Al2 2 ms, +/- 0.5 ms Analog input AI1-/AI1+ 2 ms, +/- 0.5 ms
Absolute accuracy precision	AO1 +/- 1 % for a temperature variation 60 °C AI2 +/- 0.6 % for a temperature variation 60 °C AI1-/AI1+ +/- 0.6 % for a temperature variation 60 °C
Linearity error	AO1 +/- 0.2 % AI2 +/- 0.15 % of maximum value AI1-/AI1+ +/- 0.15 % of maximum value
Analogue output number	1
Analogue output type	AO1 software-configurable logic output 10 V, <= 20 mA AO1 software-configurable voltage, analogue output range 010 V DC, impedance 470 Ohm, resolution 10 bits AO1 software-configurable current, analogue output range 020 mA, impedance 500 Ohm, resolution 10 bits
Discrete output number	2
Discrete output type	R2A, R2B configurable relay logic NO, electrical durability 100000 cycles R1A, R1B, R1C configurable relay logic NO/NC, electrical durability 100000 cy- cles



R2A, R2B <= 7 ms, tolerance +/- 0.5 ms R1A, R1B, R1C <= 7 ms, tolerance +/- 0.5 ms <= 100 ms in STO (Safe Torque Off)
Configurable relay logic 3 mA at 24 V DC
R1, R2 on resistive load, 5 A at 30 V DC, cos phi = 1, L/R = 0 ms R1, R2 on resistive load, 5 A at 250 V AC, cos phi = 1, L/R = 0 ms R1, R2 on inductive load, 2 A at 30 V DC, cos phi = $0.4$ , L/R = 7 ms R1, R2 on inductive load, 2 A at 250 V AC, cos phi = $0.4$ , L/R = 7 ms
7
PWR safety input 24 V DC, voltage limits <= 30 V, impedance 1500 Ohm LI6 switch-configurable PTC probe 06, impedance 1500 Ohm LI6 switch-configurable 24 V DC, voltage limits <= 30 V, with level 1 PLC, impedance 3500 Ohm LI1LI5 programmable 24 V DC, voltage limits <= 30 V, with level 1 PLC, impedance 3500 Ohm
LI6 (if configured as logic input)positive logic (source), < 5 V (state 0), > 11 V (state 1) LI6 (if configured as logic input)negative logic (sink), > 16 V (state 0), < 10 V (state 1) LI1LI5 positive logic (source), < 5 V (state 0), > 11 V (state 1) LI1LI5 negative logic (sink), > 16 V (state 0), < 10 V (state 1)
Automatic adaptation of ramp if braking capacity exceeded, by using resistor Linear adjustable separately from 0.01 to 9000 s S, U or customized
By DC injection
Motor thermal protection Motor power removal Motor motor phase break Drive thermal protection Drive short-circuit between motor phases Drive power removal Drive overvoltages on the DC bus Drive overheating protection Drive overcurrent between output phases and earth Drive line supply undervoltage
Drive line supply overvoltage Drive input phase breaks Drive break on the control circuit Drive against input phase loss Drive against exceeding limit speed
Drive input phase breaks Drive break on the control circuit Drive against input phase loss
Drive input phase breaks Drive break on the control circuit Drive against input phase loss Drive against exceeding limit speed
Drive input phase breaks Drive break on the control circuit Drive against input phase loss Drive against exceeding limit speed > 1 mOhm at 500 V DC for 1 minute to earth Display unit 0.1 Hz
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal
Drive input phase breaks Drive break on the control circuit Drive against input phase loss Drive against exceeding limit speed > 1 mOhm at 500 V DC for 1 minute to earth Display unit 0.1 Hz Analog input 0.024/50 Hz Male SUB-D 9 on RJ45 for CANopen 1 RJ45 for Modbus on terminal 1 RJ45 for Modbus on front face
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal   8 bits, 1 stop, even parity for Modbus on front face   1247 for Modbus   1227 for CANopen   Slave for CANopen
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal   8 bits, 1 stop, even parity for Modbus on front face   1247 for Modbus   1127 for CANopen   Slave for CANopen   CE
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal   8 bits, 1 stop, even parity for Modbus on front face   1247 for Modbus   1127 for CANopen   Slave for CANopen   CE   Vertical +/- 10 degree
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal   8 bits, 1 stop, even parity for Modbus on front face   1247 for Modbus   1127 for CANopen   CE   Vertical +/- 10 degree   5.5 kg
Drive input phase breaks   Drive break on the control circuit   Drive against input phase loss   Drive against exceeding limit speed   > 1 mOhm at 500 V DC for 1 minute to earth   Display unit 0.1 Hz   Analog input 0.024/50 Hz   Male SUB-D 9 on RJ45 for CANopen   1 RJ45 for Modbus on terminal   1 RJ45 for Modbus on front face   2-wire RS 485 for Modbus   RTU for Modbus   9600 bps, 19200 bps for Modbus on front face   4800 bps, 9600 bps, 19200 bps, 38.4 Kbps for Modbus on terminal   20 kbps, 50 kbps, 125 kbps, 250 kbps, 500 kbps, 1 Mbps for CANopen   8 bits, odd even or no configurable parity for Modbus on terminal   8 bits, 1 stop, even parity for Modbus on front face   1247 for Modbus   1127 for CANopen   Slave for CANopen   CE   Vertical +/- 10 degree




Noise level	55.6 dB conforming to 86/188/EEC			
Dielectric strength	5092 V DC between control and power terminals 3535 V DC between earth and power terminals			
Electromagnetic compatibility	Voltage dips and interruptions immunity test conforming to IEC 61000-4-11 Radiated radio-frequency electromagnetic field immunity test conforming to IEC 61000-4-3 level 3 Electrostatic discharge immunity test conforming to IEC 61000-4-2 level 3 Electrical fast transient/burst immunity test conforming to IEC 61000-4-4 level 4 Conducted radio-frequency immunity test conforming to IEC 61000-4-6 level 3			
Standards	EN 55011 class A group 2 EN 61800-3 environments 1 category C3 EN 61800-3 environments 2 category C3 EN/IEC 61800-3 EN/IEC 61800-5-1 IEC 60721-3-3 class 3C1 IEC 60721-3-3 class 3S2 UL Type 1			
Product certifications	CSA C-Tick DNV GOST NOM 117 UL			
Pollution degree	2 conforming to EN/IEC 61800-5-1			
Degree of proctection	IP54 on lower part conforming to EN/IEC 61800-5-1 IP54 on lower part conforming to EN/IEC 60529 IP41 on upper part conforming to EN/IEC 61800-5-1 IP41 on upper part conforming to EN/IEC 60529 IP21 conforming to EN/IEC 61800-5-1 IP21 conforming to EN/IEC 60529 IP20 on upper part without blanking plate on cover conforming to EN/IEC 61800-5-1 IP20 on upper part without blanking plate on cover conforming to EN/IEC 60529			
Vibration resistance	1.5 mm peak to peak (f = 313 Hz) conforming to EN/IEC 60068-2-6 1 gn (f = 13200 Hz) conforming to EN/IEC 60068-2-6			
Shock resistance	15 gn for 11 ms conforming to EN/IEC 60068-2-27			
Relative humidity	595 % without dripping water conforming to IEC 60068-2-3 595 % without condensation conforming to IEC 60068-2-3			
Ambient air temperature for operation	5060 °C with derating factor -1050 °C without derating			
Ambient air temperature for storage	-2570 °C			
Operating altitude	10003000 m with current derating 1 % per 100 m <= 1000 m without derating			

# ATV61HU75N4

# UL Type 1/IP 20 Drives


### **Dimensions without Option Card**



#### Dimensions in mm

а	b	c	G	н	к	Ø
175	295	187	158	283	6	5
Dimensions in in.						
а	b	с	G	Н	К	Ø
6.89	11.61	7.36	6.22	11.14	0.23	0.19

# Dimensions with 1 Option Card (1)



#### Dimensions in mm


а	c1	G	Н	к	Ø
175	210	158	283	6	5

#### Dimensions in in.

а	c1	G	Н	к	Ø
6.89	8.26	6.22	11.14	0.23	0.19

(1) Option cards: I/O extension cards, communication cards or "Controller Inside" programmable card.

## Dimensions with 2 Option Cards (1)



#### Dimensions in mm

а	c2	G	Н	к	Ø
175	233	158	283	6	5

Dimensions in in.



а	c2	G	н	к	Ø
6.89	9.17	6.22	11.14	0.23	0.19

(1) Option cards: I/O extension cards, communication cards or "Controller Inside" programmable card.

# ATV61HU75N4


#### Mounting Recommendations

Depending on the conditions in which the drive is to be used, its installation will require certain precautions and the use of appropriate accessories.


Install the unit vertically:

- Avoid placing it close to heating elements
- Leave sufficient free space to ensure that the air required for cooling purposes can circulate from the bottom to the top of the unit.


#### Clearance




#### Mounting Types



Type B Mounting



Type C Mounting




By removing the protective blanking cover from the top of the drive, the degree of protection for the drive becomes IP 20. The protective blanking cover may vary according to the drive model (refer to the user guide).

#### Specific Recommendations for Mounting the Drive in an Enclosure

#### Ventilation

To ensure proper air circulation in the drive:

- Fit ventilation grilles.
- Ensure that there is sufficient ventilation. If there is not, install a forced ventilation unit with a filter. The openings and/or fans must provide a flow rate at least equal to that of the drive fans (refer to the product characteristics).



- Use special filters with IP 54 protection.
- Remove the blanking cover from the top of the drive.

## Dust and Damp Proof Metal Enclosure (IP 54)


The drive must be mounted in a dust and damp proof enclosure in certain environmental conditions: dust, corrosive gases, high humidity with risk of condensation and dripping water, splashing liquid, etc.

This enables the drive to be used in an enclosure where the maximum internal temperature reaches 50°C.

# ATV61HU75N4

Wiring Diagram Conforming to Standards EN 954-1 Category 1, IEC/EN 61508 Capacity SIL1, in Stopping Category 0 According to IEC/EN 60204-1

Three-Phase Power Supply with Upstream Breaking via Contactor




- A1 ATV61 drive
- KM1 Contactor
- L1 DC choke
- Q1 Circuit-breaker
- Q2 GV2 L rated at twice the nominal primary current of T1
- Q3 GB2CB05
- S1, XB4 B or XB5 A pushbuttons
- S2
- T1 100 VA transformer 220 V secondary
- (1) Line choke (three-phase); mandatory for ATV61HC11Y...HC80Y drives (except when a special transformer is used (12-pulse)).
- (2) For ATV61HC50N4, ATV61HC63N4 and ATV61HC50Y...HC80Y drives, refer to the power terminal connections diagram.
- (3) Fault relay contacts. Used for remote signalling of the drive status.
- (4) Connection of the common for the logic inputs depends on the positioning of the SW1 switch. The above diagram shows the internal power supply switched to the "source" position (for other connection types, refer to the user guide).
- (5) There is no PO terminal on ATV61HC11Y...HC80Y drives.
- (6) Optional DC choke for ATV61H•••M3, ATV61HD11M3X...HD45M3X and ATV61H075N4...HD75N4 drives. Connected in place of the strap between the PO and PA/+ terminals. For ATV61HD55M3X...HD90M3X, ATV61HD90N4...HC63N4 drives, the choke is supplied with the drive; the customer is responsible for connecting it. For ATV61W•••N4 and ATV61W•••N4C drives, the DC choke is integrated.
- (7) Software-configurable current (0...20 mA) or voltage (0...10 V) analog input.
- (8) Reference potentiometer.

All terminals are located at the bottom of the drive. Fit interference suppressors on all inductive circuits near the drive or connected on the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.

Wiring Diagram Conforming to Standards EN 954-1 Category 1, IEC/EN 61508 Capacity SIL1, in Stopping Category 0 According to IEC/EN 60204-1

### Three-Phase Power Supply with Downstream Breaking via Switch Disconnector




- A1 ATV61 drive
- L1 DC choke
- Q1 Circuit-breaker
- Q2 Switch disconnector (Vario)
- (1) Line choke (three-phase), mandatory for ATV61HC11Y...HC80Y drives (except when a special transformer is used (12-pulse)).
- (2) For ATV61HC50N4, ATV61HC63N4 and ATV61HC50Y...HC80Y drives, refer to the power terminal connections diagram.
- (3) Fault relay contacts. Used for remote signalling of the drive status.
- (4) Connection of the common for the logic inputs depends on the positioning of the SW1 switch. The above diagram shows the internal power supply switched to the "source" position (for other connection types, refer to the user guide).
- (5) There is no PO terminal on ATV61HC11Y...HC80Y drives.
- (6) Optional DC choke for ATV61H•••M3, ATV61HD11M3X...HD45M3X and ATV61H075N4...HD75N4 drives. Connected in place of the strap between the PO and PA/+ terminals. For ATV61HD55M3X...HD90M3X, ATV61HD90N4...HC63N4 drives, the choke is supplied with the drive; the customer is responsible for connecting it. For ATV61W•••N4 and ATV61W•••N4C drives, the DC choke is integrated.
- (7) Software-configurable current (0...20 mA) or voltage (0...10 V) analog input.
- (8) Reference potentiometer.

All terminals are located at the bottom of the drive. Fit interference suppressors on all inductive circuits near the drive or connected on the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.

Wiring Diagram Conforming to Standards EN 954-1 Category 3, IEC/EN 61508 Capacity SIL2, in Stopping Category 0 According to IEC/EN 60204-1

## Three-Phase Power Supply, Low Inertia Machine, Vertical Movement




#### A1 ATV61 drive

- A2 Preventa XPS AC safety module for monitoring emergency stops and switches. One safety module can manage the "Power Removal" function for several drives on the same machine. In this case, each drive must connect its PWR terminal to its + 24 V via the safety contacts on the XPS AC module. These contacts are independent for each drive.
- F1 Fuse
- L1 DC choke
- Q1 Circuit-breaker
- S1 Emergency stop button with 2 contacts
- S2 XB4 B or XB5 A pushbutton
- (1) Power supply: 24 Vdc or Vac, 115 Vac, 230 Vac.
- (2) S2: resets XPS AC module on power-up or after an emergency stop. ESC can be used to set external starting conditions.
- (3) Requests freewheel stopping of the movement and activates the "Power Removal" safety function.
- (4) Line choke (three-phase), mandatory for and ATV61HC11Y...HC80Y drives (except when a special transformer is used (12-pulse)).
- (5) The logic output can be used to signal that the machine is in a safe stop state.
- (6) For ATV61HC50N4, ATV61HC63N4 and ATV61HC50Y...HC80Y drives, refer to the power terminal connections diagram.
- (7) Fault relay contacts. Used for remote signalling of the drive status.
- (8) Connection of the common for the logic inputs depends on the positioning of the SW1 switch. The above diagram shows the internal power supply switched to the "source" position (for other connection types, refer to the user guide).
- (9) Standardized coaxial cable, type RG174/U according to MIL-C17 or KX3B according to NF C 93-550, external diameter 2.54 mm /0.09 in., maximum length 15 m / 49.21 ft. The cable shielding must be earthed.
- (10) There is no PO terminal on ATV61HC11Y...HC80Y drives.
- (11) Optional DC choke for ATV61H•••M3, ATV61HD11M3X...HD45M3X and ATV61H075N4...HD75N4 drives. Connected in place of the strap between the PO and PA/+ terminals. For ATV61HD55M3X...HD90M3X, ATV61HD90N4...HC63N4 drives, the choke is supplied with the drive; the customer is responsible for connecting it. For ATV61W•••N4 and ATV61W•••N4C drives, the DC choke is integrated.
- (12) Software-configurable current (0...20 mA) or voltage (0...10 V) analog input.
- (13) Reference potentiometer.

All terminals are located at the bottom of the drive. Fit interference suppressors on all inductive circuits near the drive or connected on the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.

# Wiring Diagram Conforming to Standards EN 954-1 Category 3, IEC/EN 61508 Capacity SIL2, in Stopping Category 1 According to IEC/EN 60204-1

## Three-Phase Power Supply, High Inertia Machine



#### A1 ATV61 drive

- A2 Preventa XPS ATE safety module for monitoring emergency stops and switches. One safety module can manage the "Power Removal"
- (5) safety function for several drives on the same machine. In this case the time delay must be adjusted on the drive controlling the motor that requires the longest stopping time. In addition, each drive must connect its PWR terminal to its + 24 V via the safety contacts on the XPS ATE module. These contacts are independent for each drive.
- F1 Fuse
- L1 DC choke
- Q1 Circuit-breaker
- S1 Emergency stop button with 2 contacts
- S2 XB4 B or XB5 A pushbutton
- (1) Power supply: 24 Vdc or Vac, 115 Vac, 230 Vac.
- (2) Requests controlled stopping of the movement and activates the "Power Removal" safety function.
- (3) Line choke (three-phase), mandatory for ATV61HC11Y...HC80Y drives (except when a special transformer is used (12-pulse)).
- (4) S2: resets XPS ATE module on power-up or after an emergency stop. ESC can be used to set external starting conditions.
- (5) The logic output can be used to signal that the machine is in a safe state.
- (6) For stopping times requiring more than 30 seconds in category 1, use a Preventa XPS AV safety module which can provide a maximum time delay of 300 seconds.
- (7) For ATV61HC50N4, ATV61HC63N4 and ATV61HC50Y...HC80Y drives, refer to the power terminal connections diagram.
- (8) Fault relay contacts. Used for remote signalling of the drive status.
- (9) Connection of the common for the logic inputs depends on the positioning of the SW1 switch. The above diagram shows the internal power supply switched to the "source" position (for other connection types, refer to the user guide).
- (10) Standardized coaxial cable, type RG174/U according to MIL-C17 or KX3B according to NF C 93-550, external diameter
- 2.54 mm/0.09 in., maximum length 15 m/49.21 ft. The cable shielding must be earthed.
- (11) Logic inputs LI1 and LI2 must be assigned to the direction of rotation: LI1 in the forward direction and LI2 in the reverse direction.
- (12) There is no PO terminal on ATV61HC11Y...HC80Y drives.
- (13) Optional DC choke for ATV61H•••M3, ATV61HD11M3X...HD45M3X and ATV61H075N4...HD75N4 drives. Connected in place of the strap between the PO and PA/+ terminals. For ATV61HD55M3X...HD90M3X, ATV61HD90N4...HC63N4 drives, the choke is supplied with the drive; the customer is responsible for connecting it. For ATV61W•••N4 and ATV61W•••N4C drives, the DC choke is integrated.
- (14) Software-configurable current (0...20 mA) or voltage (0...10 V) analog input.
- (15) Reference potentiometer.


All terminals are located at the bottom of the drive. Fit interference suppressors on all inductive circuits near the drive or connected on the same circuit, such as relays, contactors, solenoid valves, fluorescent lighting, etc.

Product data sheet **Performance Curves** 

# ATV61HU75N4

### **Derating Curves**

The derating curves for the drive nominal current (In) depend on the temperature, the switching frequency and the mounting type (A, B or C). For intermediate temperatures (e.g. 55°C), interpolate between 2 curves.



Switching frequency Х

